

AU

```
[dvbapi]
enabled          = 1
au               = 1
pmt_mode        = 0
user            = localuser
boxtype         = dreambox
```

```
[account]
user            = localuser
au             = NC+
group          = 1
```

AU CAID 1813

Client and server has to use the same patched OSCAM.

On Client:

```
autype = 1
```

On server: It is important that Status page show client as AU ACTIVE not ON

Update of 01A0 provider is performed by EMM-S for provid 00068.

Update logged on server:

```
c    (cccam) cccam(s) <CLIENT>: EMM Request received!
c    (emm) emm:
c    (emm) 84 00 77 ...
c    (reader) Omnikey_C+ [nagra merlin] EMM: reader provid 0001A0 no match
with emm provid 000068 -> SKIP!
c    (reader) Omnikey_C+ [nagra merlin] EMM: reader provid 000000 no match
with emm provid 000068 -> SKIP!
c    (reader) Omnikey_C+ [nagra merlin] EMM: reader provid 000068 matching
with emm provid 000068 -> SEND!
c    (reader) Omnikey_C+ [nagra merlin] EMM: emmtype shared. Reader serial
#####.
c    (reader) Omnikey_C+ [nagra merlin] EMM: emm UA/SA: #####.
c (emmcache) added emmstat (reader:Omnikey_C+, count:0)
c (emmcache)  DE A7 ...
c    (reader) Omnikey_C+ [nagra merlin] EMM: emm count 0 rewrite 3
c    (reader) Omnikey_C+ [nagra merlin] EMM: emm is being sent to reader
c    (reader) Omnikey_C+ [nagra merlin] Successfully added EMM to
Omnikey_C+_shared_emm.log
r (emmcache) added emm to cache:
```

```
r (emmcache)    DE A7 ...  
r (emmcache) found emmstat match (reader:Omnikey_C+, count:0)  
r (emmcache)    DE A7 ...  
r   (reader) Omnikey_C+ [nagra merlin] ProvID 01 A0  updated  
r   (reader) Omnikey_C+ [nagra merlin] <CLIENT> emmtype=shared, len=119  
(hex: 0x77), cnt=1: written (269 ms)
```

From:

<https://niziak.spox.org/wiki/> - **niziak.spox.org**

Permanent link:

<https://niziak.spox.org/wiki/dreambox:oscams:au>

Last update: **2020/10/05 08:38**

