

Voltage divider:

- 771 gives 240V instead of 233V
- 731 gives almost OK values
- 721 gives 231V instead of 235V
- 701 gives 223V instead of 233V
- 661 gives 206V instead of 233V

Current resistor:

- 0.00131 gives 0.176A-0.179A for 0.177A
- 0.00130 gives too high amperage 0.178A-0.180A instead of 0.177A
- 0.00125 gives too high amperage 0.185A instead of 0.177A
- 0.00120 gives too high amperage 0.190A instead of 0.177A
- 0.00115 gives too high amperage 0.200A instead of 0.177A
- 0.00110 gives too high amperage
- 0.00100 gives too high amperage

From:

<https://niziak.spox.org/wiki/> - **niziak.spox.org**

Permanent link:

https://niziak.spox.org/wiki/home_automation:esp8266:hw:gosund_sp111:calibrate

Last update: **2021/01/08 20:26**

