

DS-7616NXI-K1

[DS-7616NXI-K1](#)

NOTE: Don't buy it. In 2022 it still lacks of live view in web. It requires some legacy plugin crap for Windows.

Firmware

Family tree:

- AcuSense NVR
 - Acusense K
 - 76 77 ACusense K-EUI

[Download Portal](#)

Shipped firmware:

- Firmware version: V4.71.106 build 220630
- Hardware version: V5.0 build 220624
- Web version: V4.0.1 build 220411
- Plugin version: V3.0.7.500

Next firmware:

- Firmware version: V4.73.006 build 221108
 - Fix known defects and optimize product performance
 - [Firmware_V4.73.006_221108](#)
- Code version: V5.0 build 221103
- HW B-R-K20A9_K20A9-00
- Web version: V4.0.1 build 220929
- Plugin version: V3.0.7.500
- Play library: 6.0.0.5 *

Not released:

- V4.74.000 build 230213
 - Fix known defects and optimize product performance
 - Play library: 7.3.5.0
 - Web component: V4.0.1 build 230213
 - **DO NOT INSTALL - IT BEEPS EVERY 1 MINUTE**

Next firmware:

- Firmware version: V4.74.017_230418
- Codec version: V5.0 build 230414
- Web version: V4.0.1 build 230213
- Play Library: 7.3.5.0

- Plugin version: V3.0.7.500
- Changelog:
 - https://assets.hikvision.com/prd/public/all/files/202305/K20A9_K20A9_V4.74.017%20build230418_ReleaseNotes.pdf
 - Fix known defects and optimize product performance.
- **It beeps every 1 minute**

Latest firmware:

- Firmware Version: V4.75.005 build230630
- Codec version: V5.0 build 230608
- Web version: V4.0.1 build 230617
- Play Library: 7.3.5.0
- Plugin version: V3.0.7.500
- Changelog:
 - https://www.hikvisioneurope.com/eu//portal/portal/Technical%20Materials/02%20%20NVR/00%20%20Product%20Firmware/02%20AcuSense%20NVR/Acusense%20K/01--76%2077Acusense%20K---EUI/V4.75.005/K20A9_V4.75.005build230630_ReleaseNotes.pdf
- Reason of Upgrade
 - Add new features, fix known defects, and optimize product performance.
- New features:
 - You can input user name and password when Plug-and-Play adding method
 - You can add Hikvision Switch Device to NVR, and support to configure Switch event.
 - Flexible arming and disarming with Hik-Connect. There are three ways available: Arm, Arm silently and Disarmed. You can create groups to set the arm status.
 - You can configure Flashing Alarm and Audio Alarm on local EUI.
 - You can configure Flashing Alarm and Audible Alarm on web site, and you can customize voice on Web site and Hik-Connect
 - Modify the camera name of third-party cameras and the camera which added by RTSP
 - You can quickly filter vehicle event by Search Range
 - Perimeter algorithm optimization
 - Support max and min rule

From:

<https://niziak.spox.org/wiki/> - **niziak.spox.org**

Permanent link:

<https://niziak.spox.org/wiki/cctv:hik:nvr:ds7616nxi-k1>

Last update: **2023/11/12 15:20**

