

There are 3 not connected pads on PCB: TX, RX and GND. Serial port works with 2.8V logic 115200 8N1

Unprintable (serial bit errors? Chinese characters?)characters are replaced with '?'

Console output

```
F1: 0000 0000
V0: 0000 0000 [0001]
00: 0000 0000
U0: 0000 0001 [0000]
G0: 0002 0000 [0000]
T0: 0000 00BB
Jump to BL
```

```
08-01 00-00-01-0138 SOS 1!
08-01 00-00-01-0138 SOS 3!
08-01 00-00-01-0138 SOS 2!
08-01 00-00-01-0138 SOS 3!
08-01 00-00-03-0281 NO SIM
08-01 00-00-03-0281 NO SIM
08-01 00-00-03-0281 NO SIM
08-01 00-00-03-0281 NO SIM
08-01 00-00-04-7019 Pa:123456
08-01 00-00-04-0281 NO SIM
0 pa:123456 123408-01 00-00-04-1832 number1:+48600123456
08-01 00-00-04-1832 number2:
08-01 00-00-04-1832 number3:
08-01 00-00-04-1832 number4:
08-01 00-00-04-1832 number5:
08-01 00-00-04-2714 times3:255
08-01 00-00-04-2755 ?0?^??:30
08-01 00-00-04-5337 call_admin_status=0
08-01 00-00-04-4191 ?????0,120?????????
08-01 00-00-04-4648 ACC:0
08-01 00-00-04-4808 Adata:1
08-01 00-00-04-2634 ??????????=1
08-01 00-00-04-5969 gps11:
08-01 00-00-05-0281 NO SIM
08-01 00-00-05-0281 NO SIM
08-01 00-00-11-0560 OpenGps
08-01 00-00-19-3682 newgps:0.000000 0.000000
08-01 00-00-19-3727 ACC:0 1 1
08-01 00-00-19-3735 SendSTART:1
08-01 00-00-19-0862 IMEI:123456789012345 verion:GT08_TK100_V01 2016/01/09
14:47 #####
08-01 00-00-19-0863 GSM:98, GPS:86 OK:0 #####
08-01 00-00-19-0869 ip:5.234.12.345,port:8082 #####
08-01 00-00-19-3795 ??111:30,1
```

```
08-01 00-00-19-2777 1111:5,0
08-01 00-00-19-2782 22222:5,0
08-01 00-00-19-2788 3333:5,0
08-01 00-00-19-3335 gps111:78780a130500620001000188b20d0a
08-01 00-00-29-3682 newgps:0.000000 0.000000
08-01 00-00-29-3727 ACC:0 1 1
08-01 00-00-29-3735 SendSTART:1
08-01 00-00-29-0862 IMEI:123456789012345 verion:GT08_TK100_V01 2016/01/09
14:47 #####
08-01 00-00-29-0863 GSM:91, GPS:86 OK:0 #####
08-01 00-00-29-0869 ip:5.234.12.345,port:8082 #####
08-01 00-00-29-3795 g'111:30,1
08-01 00-00-39-3682 newgps:0.000000 0.000000
08-01 00-00-39-3727 ACC:0 1 1
08-01 00-00-39-3735 SendSTART:1
08-01 00-00-39-0862 IMEI:123456789012345 verion:GT08_TK100_V01 2016/01/09
14:47 #####
08-01 00-00-39-0863 GSM:85, GPS:86 OK:0 #####
08-01 00-00-39-0869 ip:5.234.12.345,port:8082 #####
08-01 00-00-39-3795 g'111:30,1
08-01 00-00-49-3682 newgps:0.000000 0.000000
08-01 00-00-49-3727 ACC:0 1 1
08-01 00-00-49-3735 SendSTART:1
08-01 00-00-49-0862 IMEI:123456789012345 verion:GT08_TK100_V01 2016/01/09
14:47 #####
08-01 00-00-49-0863 GSM:89, GPS:86 OK:0 #####
08-01 00-00-49-0869 ip:5.234.12.345,port:8082 #####
08-01 00-00-49-3795 g'111:30,1
08-01 00-00-59-3682 newgps:0.000000 0.000000
08-01 00-00-59-3727 ACC:0 1 1
08-01 00-00-59-3735 SendSTART:1
08-01 00-00-59-0862 IMEI:123456789012345 verion:GT08_TK100_V01 2016/01/09
14:47 #####
08-01 00-00-59-0863 GSM:97, GPS:86 OK:0 #####
08-01 00-00-59-0869 ip:5.234.12.345,port:8082 #####
08-01 00-00-59-3795 g'111:30,1
08-01 00-01-09-3682 newgps:0.000000 0.000000
08-01 00-01-09-3727 ACC:0 1 1
08-01 00-01-09-3735 SendSTART:1
08-01 00-01-09-0862 IMEI:123456789012345 verion:GT08_TK100_V01 2016/01/09
14:47 #####
08-01 00-01-09-0863 GSM:100, GPS:86 OK:0 #####
08-01 00-01-09-0869 ip:5.234.12.345,port:8082 #####
08-01 00-01-09-3795 g'111:30,1
08-01 00-01-19-3682 newgps:0.000000 0.000000
08-01 00-01-19-3727 ACC:0 1 1
08-01 00-01-19-3735 SendSTART:1
08-01 00-01-19-0862 IMEI:123456789012345 verion:GT08_TK100_V01 2016/01/09
14:47 #####
08-01 00-01-19-0863 GSM:75, GPS:86 OK:0 #####
08-01 00-01-19-0869 ip:5.234.12.345,port:8082 #####
```

08-01 00-01-19-3795 g'111:30,1

From:

<https://niziak.spox.org/wiki/> - **niziak.spox.org**

Permanent link:

https://niziak.spox.org/wiki/hw:gt06_gps_tracker:serial_port

Last update: **2016/07/14 10:39**

